

# Masquerade & Indulgence

## Cleaning Guide in Health Care Applications

Whether it is hospital furniture, dental chairs or examination tables, Masquerade and Indulgence faux leathers can be used. In these applications, frequent cleaning and disinfecting are routinely performed. Evaluation of several cleaners and disinfectants has brought the following recommendations:

### Cleaning

Wipe with a mild soap (Joy, Dove, Ivory, etc.) and water solution using a soft cloth or sponge. Avoid cleaners containing abrasives or bleach. Rinse with clean water, dry with a soft cloth.

### Disinfecting

The list below names products based on testing with Masquerade and Indulgence. *Dilute* as directed and apply as per the manufacturers label instructions.

Product	Type	Manufacturer
Aseptiphene 128	Phenol / water	Huntington Labs
Bi-Arrest II	Phenol / water	Infection Control Tech.
Cetylcide	Organo ammonium chloride	Cetylite Ind. Inc.
	Organo ammonium bromides	
	Water	
Omni II	Phenol / water	ADM Medical
Precise Cleaner	Phenol	Cal Tech
Procide Spray	Glutaraldehyde / Phenol	Cottrell Ltd.
Sterall Spray	Glutaraldehyde	Colgate-Hoyt

Iodophors, such as Biocide, Wescodyne, Pro Medyne, Iodofive, etc. are not included on the acceptable list due to concerns of possible staining of the Masquerade and Indulgence surfaces. The following products are currently **not recommended** for use on Masquerade and Indulgence:

- Coefoam
- Coe Spray
- Coe Foam
- PlusHealthco Aerosol Foam Cleaner
- Lysol, Lysol II, Lysol Professional
- Asepti-steryl Aerosol
- Procide ES
- Cavicide
- Sodium Hypochlorite Solutions (Chlorine Bleach)
- Alcohols such as Isopropyl alcohol and Ethanol

Martin Brattrud endorses no particular product with regard to its specific ability to clean and/or disinfect. Martin Brattrud's approval of the listed products means only that these have shown not to harm the Masquerade and Indulgence finishes. These evaluations are based upon the products as currently formulated and may not reflect possible and future reformulations or modifications by the manufacturers.

Specific commercial disinfectants not mentioned here can be tested upon request.